

MAUBOUSSIN



Un Homme, une Vie

Mode d'emploi
Instructions for use

SOMMAIRE

I. MODE D'EMPLOI

- 1) Réglage de l'heure
- 2) Utilisation du chronographe
- 3) Réinitialisation du chronographe
(par ex. après le remplacement
de la pile)
- 4) Matériaux de votre montre
- 5) Etanchéité

II. GARANTIE INTERNATIONALE

III. CROQUIS

I. MODE D'EMPLOI

Les créations Mauboussin, de haute tradition horlogère, soulignent votre personnalité en conjuguant le temps à tous vos instants.

En choisissant cette montre Mauboussin, vous avez acquis un objet exceptionnel et rare. Lisez attentivement le mode d'emploi, il vous permettra de conserver votre montre en excellent état de marche.

Avant de vous expliquer comment régler l'heure et la date de votre montre, nous vous précisons que la couronne en « position normale », comme indiqué sur le croquis, signifie que la couronne n'est pas tirée.

1) Réglage de l'heure

Tirez la couronne jusqu'à la position 1. (*Schéma p.9*). Tournez la couronne pour régler les aiguilles des heures et des minutes. Lorsque vous renfoncez la couronne jusqu'à sa position normale, la petite trotteuse se met à tourner.

2) Utilisation du chronographe

Le compteur de 6 heures totalise les secondes de chrono. Le compteur de 9 heures totalise les minutes de chrono. Le compteur de 3 heures totalise les heures de chrono jusqu'à 24 heures. La grande aiguille rouge a la fonction de trotteuse et non de chronographe.

3) Réinitialisation du chronographe

Pour démarrer le chronographe appuyez sur le poussoir A. Pour arrêter le chronographe appuyez sur le poussoir A. La remise à Zéro du chronographe se fait avec le poussoir B.

4) Matériaux de votre montre

Votre montre a été élaborée en acier.

5) Etanchéité

Votre montre est étanche à 5 ATM.

Attention, cette garantie ne s'appliquera que si la tige de la couronne est en position normale. (cf. III. Croquis)

II. GARANTIE INTERNATIONALE

Votre montre Mauboussin est un modèle déposé par la Maison, il a été créé, développé et fabriqué selon nos critères d'exigence. Il porte, gravé au dos, le numéro d'authenticité. Ce même numéro est reporté sur votre certificat d'authenticité.

Votre montre Mauboussin, acquise auprès d'un distributeur agréé, est garantie contre toute défectuosité ou vice de fabrication pendant trois ans à compter de la date d'achat, à l'exception d'un choc sur le verre K1, du remplacement du bracelet, de la pile ou du joint d'étanchéité.

Nous vous conseillons de faire contrôler l'étanchéité de votre montre auprès d'un de nos distributeurs agréés tous les ans. Notre garantie est uniquement valable si le certificat d'authenticité est daté et contresigné par notre distributeur agréé au moment de votre acquisition.

Cette garantie, sous réserve des exclusions mentionnées ci-dessus, est totale dans les limites d'un usage normal excluant la perte, le vol, ainsi que les accidents, et dans la mesure où les interventions sont effectuées par un distributeur agréé.

La liste de nos distributeurs agréés est disponible sur demande, en vous adressant directement à :


MAUBOUSSIN

31 rue Cambacérès – 75008 Paris

Tél: +33 (0)1 44 55 10 00

www.mauboussin.fr

III. CROQUIS



CONTENTS

I. Instructions for use

- 1) Setting the time
- 2) Using the chronograph
- 3) Chronograph reset
(incl. after replacing battery)
- 4) Watch components
- 5) Water resistance

II. International guarantee

III. Sketches

I. INSTRUCTIONS FOR USE

Mauboussin time pieces are created according to high quality watchmakers standards. Your watch will complement your personality by matching the time to your moods.

By choosing this Mauboussin watch, you have acquired a rare and exceptional timepiece. These instructions for use explain clearly its operation. Please read them carefully, as they will enable you to keep your watch in perfect working order.

Before starting the time and date setting, note that "the normal position", as it's mentioned on the sketches, means that the crown is not pulled.

1) Setting the time

Pull the crown out to the 1st position. (*Plan p.19*). Turn the crown to set hour and minute hands. When the crown is pushed back to the normal position, small second hand begins to run.

2) Using the chronograph

The 6 hour chrono display counts seconds.
The 9 hour chrono display counts minutes.
The 3 hour chrono display counts hours up to 24 hours.

The big red needle has the function of a second hand and not a chronograph.

3) Chronograph reset

To start the chronograph press button A.
To stop the chronograph press button A.
Press button B to reset chronograph to the zero position.

4) Watch components

Your watch has been elaborated with steel.

5) Water resistance

Your watch is water resistant to 5 ATM.

II. INTERNATIONAL GUARANTEE

Your watch, which is a registered model, has been created, developed and manufactured according to the Mauboussin watchmakers standards. Its authenticity number is engraved on the back. This number appears on your certificate of authenticity.

The Official check stamp of the Control of Precious Metals figures where applicable and certifies the quality of the noble metals used.

Your watch, acquired from a certified dealer, is guaranteed against any defect or defective workmanship for three years from the date of purchase: with the exception of the impact on the K1 glass, the bracelet replacement, the battery replacement and

the seal replacement.

We advise you to bring back your watch each year in order to control its water-resistance.

Our guarantee is only valid if the certificate of authenticity is signed, dated and countersigned by our certified dealer at the time of purchase.

This guarantee, under the reserve of the exceptions mentioned above, is fully comprehensive within the limits of normal use except loss, theft and accidents, and under condition that any repair shall be carried out by one of our certified dealers.

For any matter related to this guarantee or any other after-sales queries, you may send us your watch directly, accompanied by its

certificate of authenticity and this booklet. In that case, we recommend that you insure the watch for transport.

Our certified dealers list is available, upon request directly to :

MAUBOUSSIN

31 rue Cambacérès – 75008 Paris

Tel: +33 (0)1 44 55 10 00

www.mauboussin.fr

III. SKETCHES

